



Installation Instruction Sheet

Part # 12-6942
Can Am Maverick 1000 (2013)
EVO UTILITY Series Dual Slip On

**BIG GUN TFI POWER BOX
RECOMMENDED WITH USE OF THIS EXHAUST.**



Parts Included

- 2 - Muffler
- 2 - Mid pipe
- 2 - Vortex Quiet Insert
- 2 - Spark Arrestor
- 2 - Exhaust Clamp
- 2 - 8mm 1.25 x 35mm Bolt
- 2 - 8mm 1.25 x 70mm Bolt
- 4 - 8mm 1.25 Lock Nut
- 6 - 8mm Washer
- 2 - Aluminum Spacer

Removal of Stock Exhaust

1. Loosen the clamps on the mid-pipes.
2. Remove the stock mufflers.

Installation of Big Gun Exhaust

1. Slide the new left and right mufflers onto the stock mid pipes. (Do not tighten)
2. Line up the mufflers to the stock muffler mounting points on the vehicle.
(Due to the manufactures inconsistency of the stock mounting tab locations, you will need to adjust the mufflers until they appear straight)
3. Using the 35mm bolts, nuts, and washers that were provided, hang the mufflers through the top mount. (Do not tighten)
4. Now, install the 70mm bolts, nuts, washers, and spacers. (Do not tighten)
5. Check alignment of the mufflers. Once it looks good, tighten all bolts. (You can rotate the mid pipes to achieve the proper alignment)

